

# EasyGate – How to install your EasyScreen



## Step 1:

Remove EasyScreen from packaging. Includes: 1 x EasyScreen with hinged side walls. 2 x foot plates. 1 x Lid. 1 x Packet fasteners.



## Step 2:

Open hinged sides. Identify the pre-drilled holes as these are the top of the EasyScreen. Attach the lid using the included Hex screws.



## Step 3:

Lay the base plates on the ground and under the EasyScreen in desired location. Be sure to place the “long edge” towards the concrete floor.



## Step 4:

Mark placement of mounting hardware. We suggest using tape for this. Allow sufficient room around your EasyScreen for air flow.



## Step 5:

Remove EasyScreen from base plate. This will allow you to fix the foot plate to the concrete floor.



## Step 6:

Drill holes using your concrete drill bit. Place anchor bolts in the holes and secure foot plates in place using 10mm spanner.



## Step 7:

Place EasyScreen back on the mounting plates and secure sides. Hint: Fasten rear first, place a level on top, fasten front second.

## What you need to install:

- Drill/Concrete drill bit 6mm
- 5/16 Hex Drive (8mm)
- Tape Measure/10mm spanner
- Masking tape/marker

Helpful Hints: Avoid over tightening bolts/screws. This is a basic install guide only as some installations may require further advice and different fasteners.